

dropcut & *juicy*

groove

7 in-one

hair trimmer



user manual

www.dropcutandjuicy.com



preparing for use:

- the appliance as supplied by the manufacturer is not yet ready for use. It must be charged prior to use.
- please connect the appliance to the USB cable to charge the appliance. It should take roundly 5-6 hours* to charge completely.
- after charging. the appliance is ready to use. It can be used with or without the clip-on comb attachment. to attach the clip-on comb attachment. slide it onto the cutting head until it clicks into position. the appliance must be switched off while the clip-on comb attachment is being attached.
- the clip-on comb attachment is adjustable. simple slide it up or down the cutting head.
- the hair can be cut to 6 different lengths ranging from approximately 1mm to 12mm. the position of the clip-on comb attachment on the cutting head determines the length of the haircut.



- after using the appliance. switch it off and connect it to the USB cable to charge it again if needed.
- in order to retain the load capacity of the storage battery we recommend using the storage battery until it is empty before recharging.

blade cleaning method:

(1) hold the clipper upright and use a brush to clean the hair debris from the blade assembly. apply 2-3 drops of lubricant between the fixed and moving blades. (see figure)

(2) remove the blade assembly, use a brush to clean the hair debris from the blade assembly, and apply 2-3 drops of lubricant between the fixed and moving blades. (see figure)

cleaning and maintenance

always turn off and unplug your appliance before you start cleaning it. clean the unit with a damp cloth.

never use detergents and solvents to clean the device.

after using the device, clean the device with the cleaning brush to remove any hair from the blades.

in order to ensure the long-term good performance of the appliance, the long-term good performance of the appliance, it is recommended to clean and refuel the appliance frequently.

use a cleaning brush to remove hair from the blades, apply 2 or 3 drops of oil, and let the machine run for a few seconds so that the unit can be properly lubricated.



understanding the warranty warranty terms and conditions

- 1.) dubstep® thanks you for showing confidence in our products and becoming our valued customers.
- 2.) to ensure a delightful product experience, dubstep® recommends reading the user manual carefully and contacting our customer care helpline to understand the product warranty period and conditions.
- 3.) dubstep® warrants that the product at the time of its original purchase free of defects in material and workmanship.

this warranty is subject to following terms:

1. the warranty is given only to original purchaser of the product
2. the warranty will be applicable for 6 months from date of original purchase or 12 months from date of import as mentioned in the import sticker on the box whichever is earlier.
3. the customer has to present proof of purchase/invoice for claiming any warranty.
4. for the entire warranty period, nu republic or its authorized representative will at their discretion repair replace defective product. repair or replacement may involve the use of the same or equivalent reconditioned unit.
5. dubstep® will return the repaired product or can replace it with another same or equivalent product to the customer in full working condition all replaced & faulty parts or components will become property of dubstep®
6. the details of the service locations can be taken from our service helpline, it is the responsibility of the customer to bring the product to the dubstep® service location at his/her own risk and expenses.
7. for any product repaired or replaced during warranty period, the repaired or replaced product shall continue to be within period of the original product
8. for any product repaired or replaced during warranty period, the repaired or replaced product shall continue to be within warranty period for the remaining time of the original warranty period of the original product.
9. in case a service centre is not available at customer location, the customer will have to courier the product to nearest Nu World service centre at his own cost.
10. one way courier cost from customer end to service centres would be borne by customer & dubstep® will bear the return courier/shipment delivery cost from service centre to customers across all regions.

who pays for what

dubstep® will pay all labour and material expenses for all repairs covered by the warranty. the customer is responsible for transporting the product for repair or arranging for its transportation and for payment of any initial shipping charges. dubstep® will pay the return shipping charges if repairs are covered by the warranty.

the warranty will not be applicable under the following circumstances:

the product code/serial number or warranty seal been removed, erased defaced altered or is illegible deterioration of the product due to normal wear use other than in accordance with the user manual rough handling. ingress of /exposure to any kind of liquid(water, sweat, beverages, oils etc.), exposure to moisture, dampness or exposure to extreme environmental conditions corrosion, unauthorized repairs, unauthorized spare parts usage accidents, forces of nature or other actions beyond reasonable control of nu republic unless the defect was caused directly by defects in material or workmanship. the warranty will also not cover any physical damage to surface of the product but not limited to scratches on the body parts. as defects caused by the fact that the battery has been short circuited or by the fact that the seals of the casing or any evidence of tampering or the product is used for equipment other than for which it is certified.

intended use / liability - dubstep@ does not accept any liability from any damage arising out of misuse of the product as prescribed by this user manual.

Process To be Followed to Claim Warranty

- The customer will raise an escalation by mailing hello@dubstepworld.com, or call our helpline +91 88262 57630.
- The customer will ship the product, the accessories, the original box, and the original sales invoice.
- The After Sales Service Centre will receive the product and check the product for any abuse, damage, scratches, breakages wear and tear.
- Once approved, the Authorized Service Centre Will send a repaired/replacement product Free of Cost to the customer. In absence of same product, a similar product may be offered to the customer.

FOR ANY CLAIM UNDER THE WARRANTY IS SUBJECT TO NOTIFICATION TO DUBSTEP@ FOR THE ALLEGED DEFECT WITHIN A REASONABLE TIME OFIT OCCURRENCE AND IN NO EVENT NOT LATER THAN EXPIRY OF WARRANTY PERIOD.

DUBSTEP® / AUTHORIZED PARTNER WILL NOT BE RESPONSIBLE FOR ANY KIND OF LOSSES - DIRECT OR INDIRECT RESULTING DUE TO ANY LOSS OF CUSTOMER DUE TO NON-FUNCTIONING. DUBSTEP OBLIGATION UNDER THIS WARRANTY SHALL BE LIMITED TO REPAIR OR PROVIDING REPLACEMENT OF PARTS ONLY THE MAXIMUM CLAIM ENTERTAINED BY NU REPUBLIC WILL BE SUBJECT TO MAXIMUM RETAIL PRICE OF THE PRODUCT OR PURCHASE PRICE (AS PER INVOICE) WHICH EVER ONE IS LOWER

For detailed terms and conditions please visit our website www.dubstepworld.com or mail us at hello@dubstepworld.com. We are also reachable on our Helpline Number: +918826257630.

Working Hours: Monday to Friday 10:00 AM-5:30 PM
(Except national and public holidays)

In event of any unforeseen circumstances, there is unavailability of certain spare parts, prevailing depreciation rules will be binding on the purchaser at accept as a commercial solution in lieu of repairs

dubstep®